

CONNECT SYSTEMS INCORPORATED

1802 Eastman Ave., Suite 116
Ventura, Ca. 93003

Phone (805) 642-7184

Fax (805) 642-7271

FLEX SERIES UNIVERSAL CONTROLLER

MULTIPROTOCOL COMMUNICATION GENERATOR

User's Instruction Manual

Made in U.S.A.

Copyright 2003 By Connect Systems Inc.

CONNECT SYSTEMS INCORPORATED

1802 Eastman Ave., Suite 116
Ventura, Ca. 93003

Phone (805) 642-7184

Fax (805) 642-7271

FLEX SERIES UNIVERSAL CONTROLLER

MULTIPROTOCOL COMMUNICATION GENERATOR

User's Instruction Manual

Version 1.01

Made in U.S.A.

Copyright 2003 By Connect Systems Inc.

TABLE OF CONTENTS

General Description	3
Connections	4
Adjustments	6
Jumper Straps	8
Multiprotocol Communication Generator Operation	9
General Hardware Description	10
Warranty	13
FCC Notice to users	14

GENERAL DESCRIPTION

The FLEX Series Universal Controller MULTIPROTOCOL COMMUNICATION GENERATOR by Connect Systems Inc. is an economical generator capable of generating DCS, CTCSS, and LTR. Special command codes available from the keypad plugged in the back of the unit allows certain parameters to be set conveniently.

Powerful built in standard features make the FLEX Series Universal Controller Multiprotocol Communication Generator the best deal going in Communication Generators today!

THE CONNECTIONS

RX AUDIO For the products detecting CTCSS, DCS, or LTR, or products that use the internal squelch, the RX AUDIO must be connected to the discriminator of the radio. For all other products the RX AUDIO can be connected to the discriminator, high side of the volume control, or the speaker.

TX AUDIO For products that generate CTCSS, DCS, or LTR, the TX AUDIO must be connected directly to the modulator of the transmitter. For LTR and DCS, the modulator must be true FM. For CTCSS the modulator can be phase modulated or FM modulated. For all other applications, connections to the high side of the microphone is acceptable.

It should be noted that in most communication controllers there is a separate line for voice audio and a separate line for the CTCSS, DCS, or LTR signals. This is because to combine the two the controller has to have a limiter on the voice line to prevent over modulation and other undesirable side effects. The Flex Series Controllers has a built in limiter thereby not requiring separate lines.

PTT The PTT normally hooks to the PTT of the transmitter. If you are using a Hand Held with the PTT sharing a common connection with the transmit audio, then attach a resistor with a value between 2.4K and 4.7K from the PTT to the TX Audio and attach the TX audio line to the center conductor of the microphone cable. In most product that use the PTT, the AUX relay can also be used as a PTT connection. This has the advantage of allowing positive keying or other situations where the normal open collector PTT does not work.

COS Connect to a point that has a good voltage swing when the squelch is opened/closed. The best point to connect is to the collector of the transistor that controls the busy light (if the receiver has one). Otherwise you may connect to the squelch control voltage. The minimum voltage for the COS is about .4 volts and the Maximum voltage is the supply voltage.

Some radios have that point coming out the back of the radio. It sometimes goes under the name of squelch detect, sq det, or COR. In some case a pull up or pull down resistor is necessary.

The polarity and other parameters associated with the COS is contained within the programming parameters

described later. It should be noted that in most cases, the COS can be replaced with the internal squelch.

SENSE This point is used as an auxiliary input for specialized purposes in certain products. As an example, this input may be used to detect the presence of a CTCSS/DCS signal in an LTR system. The minimum voltage for the sense input is about .4 volts and the Maximum voltage is the supply voltage.

The polarity and other parameters associated with the SENSE is contained within the programming parameters if used.

AUX RELAY These two points connects to the center contact and normally open contact of the relay. The use if any depends upon the product.

+12 VDC Connect to a source of 12 volts to 15 volts DC. The Flex Series Controllers are reverse polarity protected, so a polarity mistake will not damage the product. Connect the return lead to ground. The two grounds in the system are connected to each other.

ADJUSTMENTS

P1 HYB BAL

The Hybrid Balance control is used to null out the mobile return audio in full duplex mode. The alignment must take place on one of the phone lines the Flex Series controller will be serving. (This alignment can not be done at the shop prior to delivery to the site.)

Have a mobile place a call through the Flex Series Controller. The party answering the called phone should leave the phone off hook during the alignment procedure.

Monitor the transmitter output with a service monitor or connect an oscilloscope to the "TX OUTPUT" terminal on the rear of the Flex Series Controller. Place all four Dip switches in the off position.

Have the mobile simultaneously press digits 3 and 6 on his touch tone keypad. This will result in the transmission of a single 1477 Hz tone.

Adjust the "HYB BAL" Potentiometer to produce the least audio output. Try all possible dip position combinations and null each time. The combination which gives the minimum output is the correct position to use.

Changes made within the telephone company or rerouting of telephone lines could occasionally require re-adjustment of the hybrid.

P2 Not Used

P3 Tel Vox

Used for detection of call progress tones and sensitivity to voice in Vox operated applications. Turning the pot clockwise increases its sensitivity.

P4 Preamp

The preamp control is used to match the audio level from your receiver to the Flex Series controller. To adjust, a signal containing 100 Hz CTCSS with about 600 Hz deviation should be applied to the receiver. Adjust the preamp control until a level of 3 volts peak to peak is observed at test point 6. If an oscilloscope is not available, read 1 volt RMS using a VOM.

P5 RX VOX

Used in VOX mode only. Sets RX audio triggering sensitivity. Should be fully clockwise in VOX

simplex applications. Reduce setting when used through repeaters if land line cannot respond to mobile during hang time due to noise or tone on the repeater carrier.

P6 AUDIO OUT Adjust the maximum level going to the transmitter. When turned fully clockwise, an output voltage of about five volts peak to peak is obtained. In most case the output level can also be set in the programming mode.

P7 CONTRAST Sets the contrast of the LCD. Adjust to what is most pleasing to the individual.

P8 SQUELCH Advance clockwise to a point just beyond where the front panel display "Rx" message disappears. Not all products will display the Rx message.

JUMPER STRAP OPTIONS

JP1	Line In Use Detector. When inserted, enables line in use detection. That allows the system to detect if another phone in parallel with the controller is off hook. Will only work with a phone system where the nominal on hook voltage is about 48 volts.
JP2	Preamp Gain. With no jumper installed, gain is 100. With the jumper connected to the bottom two pins, the gain is about 10 with a .0047 uF capacitor giving 3 db cutoff of xxx Hz. With the jumper connect to the two pins, the gain is about 10 with a .047 uF capacitor giving a 3 db cutoff of xxx Hz.
JP3	TO BE DETERMINED
JP4	TO BE DETERMINED
JP5	TO BE DETERMINED
JP6	TO BE DETERMINED
JP7	TO BE DETERMINED
JP8	TO BE DETERMINED
JP9	TO BE DETERMINED
JP10	TO BE DETERMINED
JP11	NOT USED
JP12	NOT USED
JP13	NOT USED
JP14	NOT USED
JP15	The terminating resistor when used for RS485 communication. Only use once per system.
JP16	When inserted, allows the TX Audio output to be DC coupled.

MULTIPROTOCOL COMMUNICATION GENERATOR OPERATION

Setting Certain Parameters

To change the DCS polarity, use the command **1
To change the LTR polarity, use the command **2
To change the LTR Area bit, use the command **3
To set the LTR GOTO field, use the command **4GG
To set the internal level, use the command **5NNN

To go back to default, turn off and on the power. On power turn on, the LTR Area bit is 0, the GOTO field is 20, and the level is set at maximum or 255, and the system is generating a 100Hz CTCSS tone.

Generating a CTCSS Code

To generate a CTCSS code, use the command #1CCC where CCC is a valid CTCSS number as shown in the table below

Generating a DCS Code

To generate a DCS code, use the command #2DDD where DDD is a valid DCS code as shown in the table below.

Generating a LTR Code

To generate a LTR code, use the command #3RRIII where RR is the repeater number and III is the ID code. This system allows any repeater number or ID number to be used even if it is not valid.

Setting Output Level

The output level can be set by either the internal programming command show above or adjusting P6.

GENERAL CIRCUIT DESCRIPTION

Telephone Interface

Telephone call comes in Telco Jack J1. If the voltage exceeds about 250 volts, the two varistors, V1 and V2 will conduct and blow the two fuses F1 and F2. This protects against lightning and other high voltage transients on the telephone line.

If the systems gets a ringing voltage, the optoisolator Q1 will conduct and the output RD1 will present a square wave at the microprocessor whose frequency is the same as the incoming ringing frequency. The microprocessor will determine if it's a valid ringing signal. The optoisolator Q2 determines if the voltage on the telephone is about 48 volts. If it is the signal LB1 will be grounded. If the voltage goes below about 48 volts that point will be high.

When the telephone line is connected and the relay is pulled in, then the two optoisolators Q3 and Q4 will indicate the presence of loop current and the direction of the current. This circuit allows the system to determine if the phone line has been hung up by a momentary loss of loop current of a reversal of the loop current.

The hybrid transformers T1 and T2 along with the balancing network allows the system to separate the receive and transmit audio. This is only necessary in a full duplex phone patch.

Receive Telephone Audio

The output of T1 is presented to U1D where the Op-Amp provides an anti-aliasing filter to the Voice storage chip U17 and the DTMF decoder U3. The receive telephone audio passes to the Analog to Digital Converter on the microprocessor as the signal AD-TELCO and to the circuitry surrounding U1A where the function of Telephone Vox is implemented.

Transmit Telephone Audio

The output of the Digital to Analog Converter from the microprocessor (DA_TELCO) is passed to U19 which forms a five pole low pass filter. This circuitry is needed properly reconstruct the data coming from the microprocessor. U1B provides gain before being outputted to the telephone line.

Voice Storage Chip

The voice storage chip is used to store up to two minutes of voice from either the telephone, programming port, or the radio.

The connection from the radio to the voice storage chip is not direct. To accomplish this task, the unit digitizes the voice from

the radio and then outputs it to the telephone. If the telephone line relay is not pulled in or the system is not connected to the telephone line, then the hybrid is not balanced and the audio to the telephone output will be reflected back to the telephone audio input where it then has a clear path to the voice storage chip.

Telephone DTMF Decoder

The audio from the telephone is decoded by the DTMF decoder U3. When pin 15 on the DTMF decoder chip is high, it signals to the microprocessor pin that data is waiting where it is then read.

Radio Receive Audio

U5A provides a low pass filter used to get rid of high frequency garbage from the radio. U5B provides the de-emphasis network. The audio from U5B goes to the RX-VOX, DTMF decoder, zero crossing detector, and the 6 pole high pass filter consisting of U10A, U10B, and U10D. The output of the filter is used to remove sub audible CTCSS, DCS, or LTR tones from the radio before being presented to the microprocessors A/D converter.

The receive audio also goes to U13A-U13D, U18A and U18B which is a squelch detector. The squelch detector is used to determine the presence of squelch noise from the radio receiver.

Radio Transmit Audio

The output of the microprocessors D/A converter is reconstructed by U20, a five pole low pass filter. U4C is used to get rid of any high frequency clock noise from the audio and U4D is used to amplify the results before being presented as transmit audio.

Squelch Detector

U13A and U13B act as a four pole high pass filter to remove any low frequency signals below about 11KHz. U13 act as a gain stage where it is then detected by U13D. R110 and C92 act as a smoothing filter where it is then presented to the microprocessor via U18B

Zero Crossing Detector

U6D and U6C act as a four pole low pass filter designed to pass only the CTCSS, DCS or LTR subaudible signals. U6A and U6B along with the transistors act as a zero crossing detector where it is then presented as a digital signal to the microprocessor.

COS Detector

U4B acts as a buffer between the outside world and the A/D converter on the microprocessor. The logic within the microprocessor determines if the COS should be derived from the COS detector or the Squelch detector.

Push To Talk

Transistor Q9 acts as a buffer between the microprocessor and the outside world. D14 is used to protect the circuit against any transients.

Sense Detector

U4A acts as a buffer between the outside world and the A/D converter on the microprocessor. The logic within the microprocessor determines the function of that signal.

EEPROM

The EEPROM is used for parameter storage and occasionally certain real time data. The part is read and written to by the IIC port on the microprocessor.

Computer Interface

U12 converts the RS232 levels to levels compatible with the first UART internal to the microprocessor.

External Network

U16 converts the levels from the second UART built into the microprocessor to the appropriate levels compatible with RS485 communications. This can be used to tie multiple flex series controller together.

LCD Interface

The microprocessor talks to the LCD controller via a four bit interface.

Aux Relay

The microprocessor can turn on and off the auxiliary relay by means of a control pin attached to R93.

JTAG Interface

The microprocessor can be reprogrammed via a JTAG interface. This allows the user to change the characteristic of the controller by means of software available on our web site.

Power Supply

The power supply generates 12 volts, 5 volts, and 3.3 volts from a 12 volt or greater power source.

LIMITED WARRANTY

Connect Systems Inc. (CSI) hereby warrants our products to be free from defective workmanship for a period of one year and defective parts for a period of one year from date of sale to the initial end user. This warranty applies only to the original consumer/end user purchaser of each FLEX SERIES CONTROLLER. During the first year of warranty, CSI will repair any of its products at no charge providing the defective unit is shipped prepaid and service is performed by CSI. Conventional prevailing labor and shipping charges will apply following the end of the first year. CSI, at its sole discretion, will replace defective parts on an exchange basis for the first year of ownership by the original purchaser. All shipping cost are the responsibility of the customer.

What is not covered by this limited warranty:

This warranty shall not apply, if, in our judgment the defects are caused by misuse, lightning strikes, customer modification, water damage, negligent use, improper installation, overloads caused by external voltage fluctuations, use of unregulated power supply, damage caused by transit or handling or an abusive treatment not in accordance with ordinary product use or the product serial number has been removed, altered, or defaced. **Specific Exclusion:** This warranty specifically excludes lightning protection devices (MOVs and phone line fuses) and transistors in the PTT (Push to Talk) circuitry. These components can only fail from external abuse.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, STATEMENTS OR REPRESENTATIONS, AND UNLESS STATED HEREIN, ALL SUCH WARRANTIES, STATEMENTS OR REPRESENTATIONS MADE BY ANY OTHER PERSON OR FIRM ARE VOID. ALL IMPLIED WARRANTIES IN CONNECTION WITH THE SALE OF THIS EQUIPMENT, INCLUDING THE WARRANTY OF MERCHANTABILITY, SHALL BE OF THE SAME DURATION AS THE WARRANTY PERIOD STATED ABOVE. SOME STATES DO NOT ALLOW LIMITATIONS OF HOW LONG AN IMPLIED WARRANTY LAST, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN THE EVENT OF PRODUCT FAILURE WHICH PROVES TO BE CAUSED BY A DEFECT IN WORKMANSHIP OF MATERIALS, YOUR SOLE REMEDY SHALL BE THE REPAIR OF THE DEFECT BY CSI OR ITS APPOINTED REPAIR STATION AS STATED IN THIS WARRANTY, AND UNDER NO CIRCUMSTANCES SHALL CSI BE LIABLE FOR ANY LOSS OR DAMAGE, DIRECT, INCIDENTAL, OR CONSEQUENTIAL, ARISING OUT OF THE USE, OR INABILITY TO USE, THIS PRODUCT. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

If your new CSI product shall ever fail, contact Connect Systems Inc. Customer Service Dept. for repair and warranty information at (805) 642-7184

Note: Connect Systems Inc. reserves the right to render a modest service charge when returned units are found to be free of parts or workmanship defect(s) (i.e. operating to factory specification) within the first year of warranty. Such units will be returned freight collect to the sender, including the appropriate service charge.

APPENDIX A

FCC NOTICE TO USERS

1. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference which may cause undesirable operation.
2. This equipment generates and uses radio frequency energy and if not installed and used properly, i.e. in strict accordance with the service manual, may cause interference to radio or television reception. It has been tested and found to comply with the limits for a Class B computing device pursuant to Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when operated in a residential installation.
3. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - a. Reorient the receiving antenna.
 - b. Relocate the equipment with respect to the receiver.
 - c. Move the equipment away from the receiver.
 - d. Plug the equipment into a different outlet so that equipment and receiver are on different branch circuits.
 - e. Ensure that card mounting screws, attachment connector screws, and ground wires are tightly secured.
 - f. If cables not offered by this company are used with this equipment, it is suggested that you use shielded, grounded cables with in line filters, if necessary.
 - g. If necessary consult your dealer service representative for additional suggestions.
4. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. It is the responsibility of the user to correct such interference.