

Determining Firmware and Bootloader version of the CS7000 M17 and CS7000 M17 PLUS radios

Turn on radio in DMR mode and you should have the following Screen:



Press the "OK" button and you should get the following screen:



Press the "Down Arrow" button four times and you should get the following screen:



Press the "OK" button and you should get the following screen:



Press the "Down Arrow" button once and you should get the following screen:



Press the "OK" button and you should get the following screen:



Press the "Down Arrow" button 10 times and you should get the following screen:



This shows the firmware version!

Press the “Down Arrow” button 4 times and you should get the following screen:



This shows the bootloader version!

In you touch no keys for a few seconds the radio will go back to the startup screen as shown below.

